



## SCA Hygiene

Ailsa Street, Box Hill, Victoria

## PM4 Motor Control System

Major Upgrade Works on PM4  
MCC / CCU Monitoring and Controls

### Project Description

#### Scope of Works:

- Develop Wonderware Intouch Software, using latest version 9.5 SP1
- Configure new application to interface with Quantum PLC, using latest version DASMBTCP 1.5
- Supply and install new application
- Configure system to control over 250 Drives including Standard Forward DOL, Standard Forward/Reverse DOL, Manual Forward DOL, 3.3kV Starter and VF Drives.
- Other duties included:
  - Documentation
  - Commissioning
  - Training

